



Modifying the PICDEM™ USB Board for PIC18 Full-Speed USB Microcontrollers

Author: Rawin Rojvanit
Microchip Technology Inc.

INTRODUCTION

Microchip Technology's PICDEM™ USB Demonstration Board (DM163010) was designed as a development platform for PIC16C745/765 USB microcontrollers, prior to the introduction of the PIC184550 family of full-speed USB devices. This document describes how to modify the demo board to work with the PIC18 devices.

HARDWARE MODIFICATIONS

The PIC16 and PIC18 USB microcontrollers differ in their clock structure, as well as the use of internal pull-up resistors. The changes needed to adapt the demo board to PIC18 USB devices are relatively minor and easy to make. They are shown in the layout in Figure 1, with locations corresponding to the steps listed below.

1. Modify the external clock source:
 - a) Remove the existing 6 MHz oscillator (Y4), along with capacitors C2 and C3.
 - b) Populate the socket Y3 with a canned 20 MHz oscillator (such as DigiKey part number X119-ND or equivalent).
2. Remove resistor R1 to permit the use of the on-chip USB pull-up resistor. R2 should be left unpopulated.
3. To use the MPLAB® ICD 2 In-Circuit Debugger/Programmer with PIC18 devices:
 - a) Populate the pad J6 with a 6-wire RJ-11 jack (the standard MPLAB ICD 2 connector), such as DigiKey part number A9031-ND or equivalent.
 - b) Remove LEDs D6 and D10.
 - c) Run a jumper wire between the bottom vias (closer to the board center) of D6 and D10.
4. Populate either U3 (28-pin) or U5 (40-pin) with the appropriate PIC18 USB microcontroller.

Note: The example firmware for the PIC18 USB devices provided by Microchip assumes that the external clock source is 20 MHz.

FIRMWARE MODIFICATIONS

The example firmware for the PIC18 USB family is written with the assumption that the PICDEM FS USB Demonstration Board (DM163025) is the target platform. The PICDEM USB and PICDEM FS USB boards, however, have different board components and layouts. This requires a few basic changes to PIC18 USB firmware in order to make it run.

To show these changes, we will look at the PIC18F4550 mouse demonstration program, available on the Microchip web site (www.microchip.com/usb). When executed, it causes the screen cursor on the connected host computer to rotate in a circle.


To alter this demonstration program for use with the PICDEM USB board, it must first be installed on the host computer. This is done by downloading and executing the file, HID_setup.exe. Once it is installed:

1. In the directory, C:\MCHPFSUSB\fw\Hid\Mouse, open the MPLAB ICD 2 workspace file, MCHPUSB.mcw.
2. From the MPLAB ICD 2 toolbar, select Configure > Configuration Bits.... Change the oscillator configuration from "HS: HS+PLL, USB-HS" to "EC: EC+PLL, EC+PLL+RA6, USB-EC".
3. Open the header file, usbcfg.h, and comment out #define USE_USB_BUS_SENSE_IO.

Now you can build the project and program the microcontroller.

Note that these changes represent the bare minimum needed to make the demo application work. Should further modifications be required, or to troubleshoot other firmware issues, the user should refer to Chapter 4 of the "PICDEM™ FS USB Demonstration Board User's Guide" (DS51526) for detailed information on the Microchip USB firmware.

FIGURE 1: PICDEM™ USB BOARD LAYOUT WITH LOCATIONS OF REQUIRED HARDWARE CHANGES



COMPATIBILITY CONSIDERATIONS

It is important to note that the changes described previously represent the minimum that is required to make the demonstration work. When moving any application for PIC18F USB devices to the PICDEM USB board, certain items should always be checked.

It is very important to verify I/O assignments. For example, the status LEDs are mapped differently on the two boards: they are driven from PORTB on the PICDEM USB board, and PORTD on the PICDEM FS USB board. Also, the SPI™ module is multiplexed to different pins on the PIC16 and PIC18 USB devices. To change these items, users will need to change the `io_cfg.h` header file. Some I/O changes may require additional hardware modifications.

When using the bootloader application provided with the PICDEM FS USB application, the firmware uses a hardware signal to initiate operation. On the original PICDEM FS USB board, this operation is implemented

with a push button connected to RB4; this is not available on the PICDEM USB board. For the bootloader to work correctly, either modify the firmware to look for another hardware trigger, or add a push button switch between RB4 and ground.

The PICDEM USB board was not designed for automatic power switching. Therefore, it is always necessary to verify that jumper J3 is configured correctly for the actual power source being used.

The PICDEM USB board does not support the automatic detection of bus attachment, while the PICDEM FS USB board and PIC18 USB firmware does. Users will need to disable this feature by commenting out the `#define USE_USB_BUSSENSE_IO` statement in the `usbcfg.h` header file (for the mouse application located in the path, `C:\MCHPFSUSB\fw\Hid\Mouse\autofiles`).

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. **MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE.** Microchip disclaims all liability arising from this information and its use. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, Accuron, dsPIC, KEELOQ, microID, MPLAB, PIC, PICmicro, PICSTART, PRO MATE, PowerSmart, rfPIC, and SmartShunt are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

AmpLab, FilterLab, Migratable Memory, MXDEV, MXLAB, PICMASTER, SEEVAL, SmartSensor and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, dsPICDEM, dsPICDEM.net, dsPICworks, ECAN, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, Linear Active Thermistor, MPASM, MPLIB, MPLINK, MPSIM, PICkit, PICDEM, PICDEM.net, PICLAB, PICtail, PowerCal, PowerInfo, PowerMate, PowerTool, rfLAB, rfPICDEM, Select Mode, Smart Serial, SmartTel, Total Endurance and WiperLock are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2005, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



Printed on recycled paper.

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
=ISO/TS 16949:2002=**

Microchip received ISO/TS-16949:2002 quality system certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona and Mountain View, California in October 2003. The Company's quality system processes and procedures are for its PICmicro® 8-bit MCUs, KEELOQ® code hopping devices, Serial EEPROMS, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



MICROCHIP

WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://support.microchip.com>
Web Address:
www.microchip.com

Atlanta

Alpharetta, GA
Tel: 770-640-0034
Fax: 770-640-0307

Boston

Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago

Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Dallas

Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit

Farmington Hills, MI
Tel: 248-538-2250
Fax: 248-538-2260

Kokomo

Kokomo, IN
Tel: 765-864-8360
Fax: 765-864-8387

Los Angeles

Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608

San Jose

Mountain View, CA
Tel: 650-215-1444
Fax: 650-961-0286

Toronto

Mississauga, Ontario,
Canada
Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Australia - Sydney
Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing
Tel: 86-10-8528-2100
Fax: 86-10-8528-2104

China - Chengdu
Tel: 86-28-8676-6200
Fax: 86-28-8676-6599

China - Fuzhou
Tel: 86-591-8750-3506
Fax: 86-591-8750-3521

China - Hong Kong SAR
Tel: 852-2401-1200
Fax: 852-2401-3431

China - Qingdao
Tel: 86-532-8502-7355
Fax: 86-532-8502-7205

China - Shanghai
Tel: 86-21-5407-5533
Fax: 86-21-5407-5066

China - Shenyang
Tel: 86-24-2334-2829
Fax: 86-24-2334-2393

China - Shenzhen
Tel: 86-755-8203-2660
Fax: 86-755-8203-1760

China - Shunde
Tel: 86-757-2839-5507
Fax: 86-757-2839-5571

China - Wuhan
Tel: 86-27-5980-5300
Fax: 86-27-5980-5118

China - Xian
Tel: 86-29-8833-7250
Fax: 86-29-8833-7256

ASIA/PACIFIC

India - Bangalore
Tel: 91-80-2229-0061
Fax: 91-80-2229-0062

India - New Delhi
Tel: 91-11-5160-8631
Fax: 91-11-5160-8632

India - Pune
Tel: 91-20-2566-1512
Fax: 91-20-2566-1513

Japan - Yokohama
Tel: 81-45-471-6166
Fax: 81-45-471-6122

Korea - Gumi
Tel: 82-54-473-4301
Fax: 82-54-473-4302

Korea - Seoul
Tel: 82-2-554-7200
Fax: 82-2-558-5932 or
82-2-558-5934

Malaysia - Penang
Tel: 60-4-646-8870
Fax: 60-4-646-5086

Philippines - Manila
Tel: 63-2-634-9065
Fax: 63-2-634-9069

Singapore
Tel: 65-6334-8870
Fax: 65-6334-8850

Taiwan - Hsin Chu
Tel: 886-3-572-9526
Fax: 886-3-572-6459

Taiwan - Kaohsiung
Tel: 886-7-536-4818
Fax: 886-7-536-4803

Taiwan - Taipei
Tel: 886-2-2500-6610
Fax: 886-2-2508-0102

Thailand - Bangkok
Tel: 66-2-694-1351
Fax: 66-2-694-1350

EUROPE

Austria - Wels
Tel: 43-7242-2244-399
Fax: 43-7242-2244-393

Denmark - Copenhagen
Tel: 45-4450-2828
Fax: 45-4485-2829

France - Paris
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Munich
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Italy - Milan
Tel: 39-0331-742611
Fax: 39-0331-466781

Netherlands - Drunen
Tel: 31-416-690399
Fax: 31-416-690340

Spain - Madrid
Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

UK - Wokingham
Tel: 44-118-921-5869
Fax: 44-118-921-5820