



NOTE:

- 1) The resistors in the Pre-amplifier and Modulator / Oscillator provide the bias necessary to establish the quiescent operating point of the respective transistor.
- 2) The capacitors, aside from C1 and C2, provide a low impedance path for AC (audio and RF) signals.

**Calgary Science School
5915 Lewis Drive SW
Calgary, Alberta
CANADA T3E 5Z4**

**Original Design: A. Collinson
Modifications: G. D. Gauthier
Fabrication: Ron Ittipe and Andre De Waal**

**CALGARY SCIENCE SCHOOL PROJECT
AM B.C. BAND TRANSMITTER SCHEMATIC**

2009-12-11

Size	FSCM No.	DWG No.	Rev
A		2009 - 001	A
Scale	N/A	Sheet	1 of