



SCR Control must turn on at the zero crossing, this is achieved by synchronizing the pulse oscillator with the mains supply using a ZCD (Zero Crossing Detect) circuit. Turn on the SCR control at the Zero crossing of the AC (or 0V of DC ) & then turn off the SCR during the last required positive wave.