



Note that the PRM's VC pulse might only be 7ms long and the VTM must get 26V by the end of the VC pulse...hence soft start RC components sized accordingly... (don't make the soft start too long)

Injection resistor for feedback loop test

Error Amplifier

Instrumentation Amplifier

48Vin to 1V5 at 95 Amps

1V5, 95A, 147W = LOAD

Title		
Size	Number	Revision
A3		
Date:	29/07/2016	Sheet of
File:	C:\Altium\Vicor\Remote sense 1V5 95A.doc	3 of 3

Boards