




Wiring Diagram









AT POSITION INDICATOR CIRCUIT (AT)




OIL LEVEL WARNING CIRCUIT




CRUISE CONTROL CIRCUIT




SEAT BELT BUZZER/DOOR BUZZER



CLOCK



INTERMITT WIPER RELAY



AIR-CONDITION CIRCUITS

