


Pin 9 to Line input of Fm Tx

- S1
- 1 - INTERMITTANT
 - 2 - STEADY TONE
 - 3 - SIREN/WARBLE



R₂ Gr Blu R
 R₃ Br Blu O
 R₅ Blu Red Br
 R₆ Br Blu Y