



SW1-SW6 = N/O PUSHBUTTON SWITCH
 IC1-IC6 = SOUND EFFECTS GENERATOR IC's