

ELEC1011 Communications and Control

(4/11) Variants of AM

Pros and cons of AM (CEP 3.6)

Advantages:

- **Simple** modulator and demodulator circuits. Particularly true if the carrier is not overmodulated.

Disadvantages:

- **Wasteful of power** since the carrier consumes lots of transmit power but conveys no information (information is conveyed by the sidebands). Particularly true if the carrier is not overmodulated.
- **Wasteful of bandwidth** since the AM signal bandwidth is double that of the message.

Double SideBand Suppressed Carrier modulation (CEP 3.7.1.1)

DSBSC modulation is like AM modulation, but without the DC offset.


$$v_{dsb}(t) = v_m(t) \cdot V_c \cos(2\pi f_c t)$$

For a sinusoidal signal $v_m(t) = V_m \cos(2\pi f_m t)$ we have

$$\begin{aligned} v_{dsb} &= V_m \cos(2\pi f_m t) \cdot V_c \cos(2\pi f_c t) \\ &= \frac{1}{2} V_m V_c \cos(2\pi [f_c - f_m] t) \\ &+ \frac{1}{2} V_m V_c \cos(2\pi [f_c + f_m] t) \end{aligned}$$


The lower and upper side frequencies are retained, but the carrier is suppressed, improving the **power efficiency**. However, the DSBSC signal bandwidth is still double that of the message signal.

Figure 3.29



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Figure 3.24




Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Double SideBand Suppressed Carrier modulation (CEP 3.7.1.1)

In the time domain, the envelope crosses the x axis, causing phase reversals.


Figure 3.23



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave


DSBSC modulator (CEP 3.7.1.2)

Figure 3.25




Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Figure 3.27



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Figure 3.28



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

- In a **balanced modulator**, a positive- and negative-going square wave $v_c(t)$ having the carrier frequency f_c is used to bias the **diodes**.
- When the square wave has a positive voltage, D1 and D3 turn on, giving circuit (a). When the voltage is negative, D2 and D4 turn on, giving circuit (b).
- The **BPF** turns the enveloped square wave into an enveloped sinusoid.

DSBSC demodulator (CEP 3.7.1.3)

Since the DSBSC signal is overmodulated, we must use **coherent demodulation**.

$$v_o(t) = v_{dsb}(t) \cdot v_{LO}(t)$$




Figure 3.30 Coherent demodulation of DSB.

We can use trigonometric identity (1) from Lecture 3 to see what happens when there is a **phase difference** ϕ between the local oscillator and the carrier.

$$\begin{aligned} v_o(t) &= v_m(t)V_c \cos(2\pi f_c t) \cdot V_{cl} \cos(2\pi f_c t + \phi) \\ &= \frac{1}{2}v_m(t)V_c V_{cl} \cos(\phi) + \frac{1}{2}v_m(t)V_c V_{cl} \cos(4\pi f_c t + \phi) \end{aligned}$$

After the LPF we get


$$v'_m(t) = \frac{1}{2}v_m(t)V_c V_{cl} \cos(\phi)$$

Note that $v'_m(t)$ is attenuated altogether when $\phi = \pi/2$, which corresponds to a 90° phase difference. This is the **quadrature null effect**.

DSBSC demodulator (CEP 3.7.1.3)

The quadrature null effect motivates the Costas loop.

Figure 3.31




Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

This adjusts the local oscillator frequency until the signal $K \sin(\phi)v_m(t)$ is completely attenuated, leaving the desired signal $K \cos(\phi)v_m(t)$ completely unattenuated.

Quadrature Amplitude Modulation (CEP 3.7.1.3)

- QAM improves the **bandwidth efficiency** of DSBSC by transmitting two message signals $v_{mi}(t)$ and $v_{mq}(t)$ in the same band, by using **in-phase** and **quadrature-phase** carriers having the same frequency.
- The QAM signal bandwidth is double the maximum of the two message signal bandwidths.



- The quadrature message signal $v_{mq}(t)$ must be initially turned off in order to allow the **Costas loop** to perform **carrier recovery**.

Mathematics

We need some more trigonometric identities

$$\cos\left(A - \frac{\pi}{2}\right) = \sin(A) \quad (1)$$

$$\cos(A - \pi) = -\cos(A) \quad (2)$$

Using trigonometric identity (1) from Lecture 3 and the identities above, we can derive even more identities

$$\cos^2(2\pi ft) = \frac{1}{2} + \frac{1}{2} \cos(4\pi ft) \quad (3)$$

$$\sin^2(2\pi ft) = \frac{1}{2} - \frac{1}{2} \cos(4\pi ft) \quad (4)$$

$$\cos(2\pi ft) \sin(2\pi ft) = \frac{1}{2} \sin(4\pi ft) \quad (5)$$

Mathematics

In QAM we have

$$v_{qam}(t) = v_{mi}(t)V_c \cos(2\pi f_c t) + v_{mq}(t)V_c \sin(2\pi f_c t)$$

Using identities (3) and (5) from above we can see how the **in-phase** carrier is demodulated

$$\begin{aligned} v_{oi}(t) &= v_{qam}(t) \cdot V_{cl} \cos(2\pi f_c t) \\ &= [v_{mi}(t)V_c \cos(2\pi f_c t) + v_{mq}(t)V_c \sin(2\pi f_c t)] \cdot V_{cl} \cos(2\pi f_c t) \\ &= \frac{1}{2}V_c V_{cl} v_{mi}(t) + \frac{1}{2}V_c V_{cl} v_{mi}(t) \cos(4\pi f_c t) + \frac{1}{2}V_c V_{cl} v_{mq}(t) \sin(4\pi f_c t) \end{aligned}$$

The LPF gives

$$v'_{mi}(t) = \frac{1}{2}V_c V_{cl} v_{mi}(t)$$

Mathematics

Similarly, the **quadrature-phase** carrier is demodulated using identities (4) and (5)

$$\begin{aligned}v_{oq}(t) &= v_{qam}(t) \cdot V_{cl} \sin(2\pi f_c t) \\&= [v_{mi}(t)V_c \cos(2\pi f_c t) + v_{mq}(t)V_c \sin(2\pi f_c t)] \cdot V_{cl} \sin(2\pi f_c t) \\&= \frac{1}{2}V_c V_{cl} v_{mq}(t) - \frac{1}{2}V_c V_{cl} v_{mq}(t) \cos(4\pi f_c t) + \frac{1}{2}V_c V_{cl} v_{mi}(t) \sin(4\pi f_c t)\end{aligned}$$


The LPF gives

$$v'_{mq}(t) = \frac{1}{2}V_c V_{cl} v_{mq}(t)$$

Single SideBand Suppressed Carrier (CEP 3.7.2)

- In DSBSC, the sidebands are mirror images of each other. SSBSC transmits only one sideband in order to improve **spectral efficiency**.
- The SSBSC signal bandwidth is equal to the message bandwidth.
- A tighter band-pass filter can be used to reject noise, improving the **signal to noise ratio**.
- Also, a lower bandwidth implies less sensitivity to **frequency-selective fading**.

Figure 3.33




Taken from *Communication Engineering Principles*, © Ifoik Otung, published 2001 by Palgrave

SSBSC frequency discrimination modulator (CEP 3.7.2.2)


- A filter can be used to remove the unwanted sideband.
- This only works if the lowest frequency f_1 in the message signal is somewhat higher than 0 Hz.
- To remove the upper sideband, the filter must retain the frequencies below $f_c - f_1$, but reject the frequencies above $f_c + f_1$.
- A highly-selective filter having a **high complexity** will be required if f_1 is low and f_c is high.
- **Low-complexity** filters can be used if the modulation is performed in stages.

Figure 3.35



Taken from *Communication Engineering Principles*, © Iliok Otung, published 2001 by Palgrave

Figure 3.36



Taken from *Communication Engineering Principles*, © Iliok Otung, published 2001 by Palgrave

SSBSC phase discrimination modulator (CEP 3.7.2.2)

This uses QAM modulation of the message signal and a version in which every frequency component has its phase shifted by 90° .

Consider a sinusoidal message signal

$$v_m(t) = V_m \cos(2\pi f_m t)$$

We need the trigonometric identities

$$\cos(2\pi f_1 t) \cos(2\pi f_2 t) = \frac{1}{2} \cos(2\pi |f_1 - f_2| t) + \frac{1}{2} \cos(2\pi |f_1 + f_2| t) \quad (6)$$


$$\sin(2\pi f_1 t) \sin(2\pi f_2 t) = \frac{1}{2} \cos(2\pi |f_1 - f_2| t) - \frac{1}{2} \cos(2\pi |f_1 + f_2| t) \quad (7)$$

We have

$$\begin{aligned} v_{ssb}(t) &= V_m V_c \cos(2\pi f_c t) \cos(2\pi f_m t) - V_m V_c \sin(2\pi f_c t) \sin(2\pi f_m t) \\ &= V_m V_c \cos[2\pi(f_c + f_m)t] \end{aligned}$$

Adding the two product modulator outputs gives the lower sideband.

Figure 3.37




Taken from *Communication Engineering Principles*, © Iliok Otung, published 2001 by Palgrave

SSBSC demodulator (CEP 3.7.2.3)

Figure 3.38

Coherent demodulation uses a local oscillator signal $v_{LO}(t) = V_{cl} \cos(2\pi f_c t)$ to demodulate the SSBSC signal $v_{ssb}(t) = V_m V_c \cos[2\pi(f_c + f_m)t]$



We get

$$\begin{aligned}
 v_o(t) &= v_{ssb}(t) \cdot v_{LO}(t) \\
 &= V_m V_c \cos[2\pi(f_c + f_m)t] \cdot V_{cl} \cos(2\pi f_c t) \\
 &= V_m V_c V_{cl} \cos[2\pi f_m t] + V_m V_c V_{cl} \cos[2\pi(2f_c + f_m)t]
 \end{aligned}$$

The LPF recovers the sinusoidal message signal

$$v'_m(t) = V_m V_c V_{cl} \cos(2\pi f_m t)$$

Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

SSBSC demodulator (CEP 3.7.2.3)

Suppose there is a **phase error** ϕ in the local oscillator signal

$$v_{LO}(t) = V_{cl} \cos(2\pi f_c t + \phi)$$

In this case we get

$$\begin{aligned} v_o(t) &= v_{ssb}(t) \cdot v_{LO}(t) \\ &= V_m V_c \cos[2\pi(f_c + f_m)t] \cdot V_{cl} \cos(2\pi f_c t + \phi) \\ &= V_m V_c V_{cl} \cos[2\pi f_m t - \phi] + V_m V_c V_{cl} \cos[2\pi(2f_c + f_m)t + \phi] \end{aligned}$$

There will be a corresponding phase error in the recovered message signal

$$v'_m(t) = V_m V_c V_{cl} \cos(2\pi f_m t - \phi)$$


In DSBSC, a **phase error** causes **attenuation** of the recovered message signal, which is not very harmful and is easy to fix.

In SSBSC, a **phase error shifts the phase** of every frequency component in the message signal by ϕ , which is very harmful and is difficult to fix.

Independent SideBand Modulation (CEP 3.7.3 and 3.7.3.1)


- Independent messages are transmitted on the two sidebands of a carrier.
- Modulation is achieved by adding the outputs of two frequency or phase discrimination SSBSC modulators.

Figure 3.39



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Figure 3.40




Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Independent SideBand Demodulation (CEP 3.7.3.2)

- Filtering is required to discriminate between the upper and lower sidebands during demodulation.
- A **superheterodyne** receiver is typically used to avoid the requirement for high selectivity filtering at high frequencies.

Figure 3.41




Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Vestigial SideBand Modulation (CEP 3.7.4)


- All but a vestige of the lower sideband is filtered away before transmission.
- The filter response is such that $H_{vsb}(f_c - f) + H_{vsb}(f_c + f) = 1$ for $0 \leq f \leq B_v$.
- As a result during coherent demodulation, the vestige of the lower sideband compensates for the attenuated frequencies in the upper sideband.
- The VSB signal bandwidth is given by $f_m + B_v$.

Figure 3.43



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Figure 3.44



Taken from *Communication Engineering Principles*, © Ifiok Otung, published 2001 by Palgrave

Exercise

$$v_{m1}(t) = 2 + \sin(40\pi t) + 3 \cos(60\pi t)$$

$$v_{m2}(t) = 3 \cos(20\pi t + \pi/4) + 2 \sin(60\pi t) - \cos(100\pi t)$$

1. Sketch the amplitude and phase spectrum of the signal $v_{dsb}(t)$ that results when the signal $v_{m1}(t)$ is DSBSC modulated onto a 1 kHz carrier having an amplitude of $V_c = 1$.
2. Sketch the amplitude and phase spectrum of the VSB signal $v_{vsb}(t)$ that results when the DSBSC signal $v_{dsb}(t)$ is filtered according to

$$H_{vsb}(f) = \begin{cases} 0 & \text{if } f < 975 \\ 1 & \text{if } f > 1025 \\ (f - 975)/50 & \text{otherwise} \end{cases}$$

3. Sketch the amplitude and phase spectrum of the signal $v_{ssb}(t)$ that results when phase discrimination is used to SSBSC modulate the signal $v_{m2}(t)$ onto the upper sideband of a 1 kHz carrier having an amplitude of $V_c = 1$.

Exercise continued

4. Sketch the amplitude and phase spectrum of the signal $v_{isb}(t)$ that results when the signals $v_{m1}(t)$ and $v_{m2}(t)$ are respectively ISB modulated onto the lower and upper sidebands of a 1 kHz carrier having an amplitude of $V_c = 1$.
5. Sketch the amplitude and phase spectrum of the signal $v_{qam}(t)$ that results when the signals $v_{m1}(t)$ and $v_{m2}(t)$ are respectively QAM modulated onto in-phase and quadrature-phase 1 kHz carriers having amplitudes of $V_c = 1$.
6. For each case above, state the signal bandwidth.
7. For the cases in questions 1 to 3, sketch the amplitude and phase spectrum of the signal $v_o(t)$ obtained after the first step of the coherent demodulator.
8. For the case in question 5, sketch the amplitude and phase spectrum of the signals $v_{oi}(t)$ and $v_{oq}(t)$ obtained during the coherent demodulation of the in-phase and quadrature-phase carriers, respectively.