Power Supplies

Feature

Why Switchmode Power Supplies Need PFC

۲

n AC-DC switchmode power supply without power factor correction (PFC) can draw approximately 950 Watts from a typical 115VAC wall socket protected by a 15A circuit breaker before exceeding the UL mandated limit of 12A. A simple load like a toaster can draw almost 1400 Watts. The difference between the two is due to the higher power factor (PF) of the toaster, which presents a resistive load to the power line. If we correct the power factor of the switchmode supply, it can then draw about as much power as the toaster, allowing it to provide more output power to its load from the same 115VAC/15A wall socket.

What is power factor correction (PFC)?

Power factor (PF) is technically the ratio of real power consumed to the apparent power (Volts-RMS x Amps-RMS), and is expressed as a decimal fraction between 0 and 1. PF is traditionally known as the phase difference between sinusoidal voltage and current waveforms. When the AC load is partly capacitive or inductive, the current waveform is out of phase

۲

with the voltage (Fig. 1). This requires additional AC current to be generated which isn't consumed by the load, creating I2R losses in the power lines.

An electric motor is inductive, especially when it is starting. The current waveform lags behind the voltage waveform, dropping the PF to well below 1 (similar to Fig. 1). This is why many motors have "starting" capacitors installed to counteract the inductance, and therefore correct the PF during motor startup.

A simple resistive load has the highest PF of 1. An AC voltage across the resistor causes an AC current which is identical to and in-phase with the voltage waveform (Fig. 2).

A switchmode power supply when viewed as an AC load is neither capacitive nor inductive, but non-linear. A switchmode supply conducts current in short pulses or spikes that are in-phase with the line voltage (Fig. 3). The product of Volts-RMS x Improving the power factor Low power factors can be improved via power factor correction (PFC) circuits. The types used

Amps-RMS is considerable higher than the real

power consumed, and thus the PF is much less

than 1, typically around 0.65 or less.

for switchmode power supplies 'smooth out' the pulsating AC current, lowering its RMS value, improving the PF and reducing the chances of a circuit breaker tripping. There are two basic types of PFC: active and passive. Active PFC is more effective, a bit more expensive, generally inte-

Figure 1. Voltage and current waveforms are sinusoidal but out-of-phase; PF <1.

Figure 2. Voltage and Current waveforms are sinusoidal and in-phase; PF=1.



Figure 3. Voltage waveform is sinusoidal, current waveform is non-sinusoidal but in-phase; PF<1.

For example, UL limits a system's line current to 80 % of the circuit breaker's rating. For a typical 15A breaker, 12A is the maximum allowed, and the best-case power available is therefore 120VAC x 12A = 1440 Watts. Referring to the above equation, here are two examples of supplies with different power factors:

 \bullet A switch-mode supply with 0.65 PF and 85%efficiency can only deliver (120 x 12 x 0.65 x 0.85) = 796 Watts (Pout).

• However, if the power factor is corrected to 0.98, the same power supply can now deliver (120 x 12 x 0.98 x 0.85) = 1200 Watts (Pout), a 51% increase.

Meeting international regulations

Since switchmode power supplies without PFC tend to draw the AC line current in a non-linear fashion, many unwanted harmonic currents are generated and reflected back on the AC power lines. For example, the first harmonic is the primary input frequency, typically 50 Hz for the EU countries. The third harmonic is 150 Hz, and the 39th harmonic is 1,950 Hz. These unwanted harmonic currents have a direct relationship to the power factor of switchmode power supplies.

An important reason to have PFC within your power supply is to comply with international regulations, especially if you intend to sell your equipment in Europe. Since 2001, the European Union (EU) established limits on harmonic currents that can appear on the mains (AC line) of switchmode power supplies. Today, the most important regulation is the 'European Norm' EN61000-3-2. This regulation applies to power supplies with input power of 75 watts or greater, and that pull up to 16 amps off the mains. It sets severe limits on the harmonic currents up to the 39th, when measured at the input of switchmode power supplies. Power supplies with PFC circuits that meet EN61000-3-2 inherently have high power factors that are typically 0.97 or better.

Summary

As previously mentioned, power line harmonics are created whenever the line current is not a pure sinewave, as is the case with a switchmode power supply's input, which tend to have 'pulsed' currents (Fig 3). Measuring power line harmonics is a mathematical means to describe a complex waveform's power factor by resolving it into a fundamental frequency and its many harmonics. The harmonic currents do not contribute to the output load power, but cause unwanted heating in the wall socket, wiring, circuit breaker, and distribution transformers.

PFC significantly reduces harmonics, resulting in almost a pure 'fundamental' current frequency that will be in-phase with the voltage waveform (Fig. 2). International regulations dictate the substantial attenuation of harmonic currents. The vast majorities of AC-DC power supplies manufactured by Lambda Americas employ active PFC, are in accordance with EN61000-3-2 and provide typical power factors in the range of 0.97 to 0.99.

This article was contributed by Lambda Americas. www.lambdapower.com



Typical 1000-Watt Switchmode Power Supply

grated into the switchmode power supply, and can

achieve a PF of about 0.98 or better. Passive PFC

is less expensive and typically corrects the PF to

To determine just how much more power is avail-

able from the AC line and a power supply with

PFC, the user needs to understand the following

equation, which defines the amount of output

power (Pout) available from a switchmode supply:

with PFC (meets EN61000-3-2)

about 0.85.

Power Factor = .98, Efficiency = 88%

Harvesting additional

Pout = VL-RMS x IL-RMS x PF x Eff.

output power



High-Quality, Reliable Power Supplies











SPACERS • NUTS • WASHERS www.microplastics.com

for handheld and portable devices

Key Features • Bright gold-plated contacts (over base metal) - particularly effective in outdoor or humid environs • Resists tarnish or corrosion • Unique design keeps coin-cell firmly secured, with dual beams for assured contact • Gold's low resistance (30 M Ω max.) helps extend battery life Break-resistant, lightweight LCP plastic body resists high temperatures . Lead-free reflow process, compatible to over 300°C • Pick and place compatible • Shock and vibration resistant • Available for CR-2032 and other size coin-cell batteries • Thru-pin and surface mounting • Available tape and reel • Requires no tool for battery removal

For details: write, call, fax or visit our website

MPD

MEMORY PROTECTION DEVICES, INC.

200 BROAD HOLLOW RD., FARMINGDALE, NY 11735 TEL (631) 249-0001 / FAX (631) 249-0002 www.batteryholders.com

۲

for your Peace of Mind **Complete products made for your** specific needs with your brand name

- All types of Power Supplies from 5W - 150W.
- Switch-mode, wall-mount P.S. with universal interchangeable plugs.
- More than 1000 models to meet your requirements.
- · All products are RoHS compliant.
- Most products meet CEC Requirements and are Energy Star Qualified.
- North America, Europe, UK, Japan safety approvals



For more details please visit our websites at www.LQP.ca or www.LEADINGQP.com

Drop us a line, we are more than happy to provide you a quote:

jack@leadingqp.com

LQP Enterprises Co Burnaby (Vancouver) BC Tel: 604 451 7899 Fax: 604 451 7858

Canadian Electronics February 2008

www.canadianelectronics.ca